



NOTES

1. For best results, cut template out using a ruler and an exacto blade or razor. For accurate folding, use your blade and ruler to scribe a very light line along the fold lines. Bonding can be done with a glue stick and is easily removed using cold running water.
2. Prior to attaching template, trim and fit front of blank to your front trunion first, then attach template aligning it with the front. Work from the front to the rear.
3. Always drill and cut undersized, then slowly fit to your parts.
4. Never rely on templates for trunion holes as all kits differ slightly. Always measure off your existing trunions and drill accordingly.

AK-47 RECEIVER BLANK TEMPLATE			
WARNING: ALL BATF RULES APPLY			
DATE:	5 JAN 2004	REV	2
SCALE	1:1	CREATED BY:	ACE ARMS
		PAGE:	1 of 1

